

# **Assembly Instructions**

ITEM NO. D5524-20

FLAIR DINING CHAIRS
(2 PCS/CTN)

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items and compare with the PARTS LIST and/or HARDWARE LIST shown below.




Please read the instructions thoroughly before assembly.

- 1.We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- 2. Please do not tighten screws or bolts until the assembly is completed.
- 3. To level the chairs or table, before tightening all the screws, the chairs or table must be placed on a flat surface and then tighten the screws.
- 4. Please put all parts on a non-abrasive floor before assembly and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

## **PARTS LIST**

### HARWARE LIST

NO.	COMPONENT	SKETCH	QTY
А	CHAIR BACK		2PCS
В	SEAT		2PCS
C1	RIGHT SIDE FACING (RSF) LEG		2PCS
C2	LEFT SIDE FACING (LSF) LEG		2PCS
D1	RIGHT SIDE FACING (RSF) STRETCHER		2PCS
D2	LEFT SIDE FACING (LSF) STRETCHER		2PCS



NO.	COMPONENT	SKETCH	QTY
1	FLAT WASHER 1/4" DIA.		22 PCS
2	SPRING WASHER 1/4" DIA.		22 PCS
3	SHORT BOLT 1/4" x 1 9/16"		6 PCS
4	MEDIUM BOLT 1/4" x 2 3/8"		8 PCS
5	LONG BOLT 1/4" x 3"	(a)—)))))))))))	8 PCS
6	ALLEN WRENCH (4mm)"		1 PC
7	WOOD SCREW 1/4" x 1 9/16"	( <del>)</del>	8 PCS

**MADE IN VIETNAM** 

**PAGE: 1 OF 3** 



# **Assembly Instructions**

ITEM NO. D5524-20

FLAIR DINING CHAIRS (2 PCS/CTN)

To assemble the chairs, please follow the following steps and repeat for each chair:

STEP 1 Place the chair back (A) on a soft and clean surface. Assemble the seat (B) with the chair back (A) by using Allen Wrench (6) with hardware 1,2, and 3. Then assemble the seat (B) with the back legs of the chair back (A) using Allen Wrench (6) with hardware 1,2, and 5


\*Attention: DO NOT TIGHTEN THE BOLTS.

# \*Please use short bolt

### STEP 2

Assemble the front legs (C1) and (C2) with the seat (B) by using Allen Wrench (6) with hardware 1,2, and 4.


\*Attention: DO NOT TIGHTEN THE BOLTS



### STEP 3


Install both RSF Stretcher (D1) and LSF Stretcher (D2) to chair back (A) and front legs (C1) and (C2) by using a screw driver with hardware 7.

\*Attention: DO NOT TIGHTEN THE SCREWS



### STEP 4

To level the chair, stand the chair up on a flat surface and tighten all the bolts by using Allen Wrench (6) and tighten all the screws by using a screw driver.



**MADE IN VIETNAM** 

PAGE: 2 OF 3




# **Assembly Instructions**

ITEM NO. D5524-20 FLAIR DINING CHAIRS (2 PCS/CTN)

## STEP 5

Repeat STEP 1 through STEP 4 to assemble the other chair.



Fully Assembled Chair

MADE IN VIETNAM

PAGE: 3 OF 3